










Britzy SWITCHES





 Technical data p. 13-14

SWITCHES

- All switches are ISI marked as per latest IS 3854:1997
- Finger-proof terminal for protection against accidental contact
- Laser marking for easy identification






PACK	CAT. NOS		No. of modules
20/200	6734 01	 6 A Switch SP 1 way	01
20/200	6734 02	 6 A Switch SP 2 way	01
20/200	6734 03	 6 A Switch SP 1 way with Indicator	01
20/200	6734 11	 16 A Switch SP 1 way	01
20/200	6734 12	 16 A Switch SP 2 way	01
20/200	6734 13	 16 A Switch SP 1 way with indicator	01
20/200	6734 24	 25 A Switch SP 1 way with indicator	01
10/100	6734 25	 20 A DP Switch with indicator	02
10/100	6734 26	 32 A DP Switch with indicator	02

PUSH BUTTONS




20/200	6734 04	 6 A Bell push with indicator	01
10/100	6734 06	 6 A Bell push with indicator	02

SOCKETS

- Confirming to IS 1293:2005
- Shuttered socket for child safety
- Shutter open only with phase and neutral insertion simultaneously

PACK	CAT. NOS		No. of modules
10/100	6734 52	 6 A 3 pin Universal socket	02
20/200	6734 53	 Euro US socket	01
10/100	6734 55	 6/16 A socket 3Pin	02
10/100	6734 56	 25 A socket 3Pin	02
10/100	6734 54	 Multistandard socket	02

DATA & VOICE

20/200	6734 41	 RJ11 telephone socket	01
20/200	6734 44	 Double RJ11 telephone socket	01
20/200	6734 45	 RJ45 Cat 6 computer socket	01

TELEVISION SOCKET

20/200	6734 46	 TV socket	01
--------	----------------	---	----